518A.3 | 518A - Vice pliers for bodywork



Description:

• Bodywork vice pliers for tacking and welding operations of automotive bodywork elements. - 518A.1: Ultra wide nose pliers. - 518A.2: Clearance pliers. - 518A.3: Wide pliers. - 518A.4: Compact clearance pliers. - 518A.5: Compact pliers.

	518A.3
Length L [mm]	210
Height H [mm]	45
Length [mm]	50.0