

## E200527 | EXPERT PLIERS FOR CLIC CLAMPS



### Description:

- Pliers for circlips: To tighten and close clic clamp type CV boot clamp / pipe clamp.
- Applicable on Audi, BMW, Chrysler, Ford, GM, Honda, Mazda, Mercedes, Nissan, Opel/Vauxhall, VW, etc

	E200527
Weight [g]	464.0
Height [mm]	2.0