

E200530 | EXPERT PLIERS FOR CLAMPS WITH SQUARE DRIVE



Description:

- Pliers for circlips: for fitting stainless steel clamps on drive shafts and CV boot where a torque setting is required.
- Application: VW, Audi, Vauxhall, Skoda, Opel, Ford, etc.,

	E200530
Weight [g]	890.0
Height [mm]	3.5