

196.TMS | BRAKE SPRING PLIERS



Description:

- To remove the springs from the fittings.
- Right and left hand work.