

DCR.SR Injector gaskets slide hammer**Description:**

- To pull injector gaskets blocked at the bottom of the injector well.
- Avoids cylinder head removal.