

U.16A18 U.16 - Ball joint pullers**Description:**

- Used to dismount steering and suspension ball joints.
- Supplied with a set of 2 spare safety pins.
- U.16-05J3: Set of 3 pins for U.16B and U.16A18.
- U.16-A45-05J3: Set of 3 shear pins for U.16B32 and U.16B45.

| | |
|---------------|-------|
| A [mm]: | 45 |
| d [mm]: | 16 |
| Width l [mm]: | 100 |
| [kg]: | 0,635 |