

**U.16B U.16 - Ball joint pullers****Description:**

- Used to dismount steering and suspension ball joints.
- Supplied with a set of 2 spare safety pins.
- U.16-05J3: Set of 3 pins for U.16B and U.16A18.
- U.16-A45-05J3: Set of 3 shear pins for U.16B32 and U.16B45.

A [mm]:	45
d [mm]:	22
Width l [mm]:	100
[kg]:	0,665

