

U.7-3T | AXIAL BALL JOINT EXTRACTOR



Description:

- BALL JOINT SEPARATOR .
- Used to disassemble and assemble steering ball joints.
- This functional and compact inner tie rod removal tool set makes easy to replace all type of inner tie rods of cars as well as light commercial vehicles.
- Thanks of the 3 models of adaptable cages this tool covers the largest range of different shapes and size of tie rods heads from a diameter of 28mm to 45mm.
- Head diameter: 30
- L. x W.: 420 x 82 mm.



U.7-3T